


EMUL-68HC912D60 Layout

This is the top view looking down on to the target board or on top of the 68HC912D60 personality card.

Version 2.1

December 17, 2001

Top View - 68HC912D60



- 1) The grayed out pins are not connected. They are physically located on the bottom of the emulator board but are not used on the personality card. They are for future expansion.
- 2) The target microcontroller needs to be removed from the target since the HC12 family cannot tri-state.
- 3) The target adapters do not plug into the top of the emulator, they plug into the bottom side.

Helpful measurements when laying out the board:

- On the top side, the emulator expands 0.2".
- On the bottom side, the emulator expands 4.3".
- On the left side the emulator expands 0.3".
- On the right side the emulator expands 0.6".



